



GOLD SD 11 effektvariant 2, 12 eff.var. 1 och 2/cap.var. 1 and 2 Med styrenhet/With control unit



¹⁾ Inställning DIP-switch. Switch nr. 1-5. 1 = On, 0 = Off. /
Settings DIP switch. Switch no. 1-5. 1 = On, 0 = Off.

GOLD SD 11 effektvariant 2, 12 eff.var. 1 och 2/cap.var. 1 and 2 Utan styrenhet/Without control unit




1) Inställning DIP-switch. Switch nr. 1-5. 1 = On, 0 = Off./
Settings DIP switch. Switch no. 1-5. 1 = On, 0 = Off.


GOLD SD 11 effektvariant 2, 12 eff.var. 1 och 2/cap.var. 1 and 2

Sammankoppling av aggregat med styrenhet till aggregat utan styrenhet/


Connecting AHU with control unit to AHU without control unit



A:



J: GOLD RX/PX/CX/SD 04-50



K: GOLD RX/PX/CX/SD 04-50

