

SW	Register	R / W	Register Name	Min	Max	Unit	Description	Note
USER SETTINGS								
3.0->	4x5001	RW	Operating Mode	0	5		0= Shutdown, 1 = Away, 2 = Home, 3 = Boost, 4 = Travelling, (5 = Home+ included in SW4.0 Genius)	
3.0->	4x5102	RW	Boost mode timer	0	5		0 = Continuous, 1 = 30min, 2 = 60min, 3 = 90min, 4 = 120min, 5 = 240min	
4.0->	4x5108	RW	Home + mode ventilation level	10	90	%	0% corresponds to the Home mode and 100% the Boost mode ventilation level	
4.0->	4x5203	RW	Home+ visibility in User Panel	0	1		0=Not visible/disabled 1 = Enabled	User Panel visibility
3.0->	4x5106	RW	Travelling mode speed drop	0	10	%	Traveling mode ventilation reduction from away mode	
3.0->	4x5202	RW	Travelling visibility in User Panel	0	1		0=Not visible/disabled 1 = Enabled	User Panel visibility
3.0->	4x5207	RW	Shutdown visibility in User Panel	0	1		0 =Not visible/disabled 1 = Enabled	User Panel visibility
3.0->	4x5018	RW	Emergency Stop	0	2		0 = Emergency stop disabled, 1 = Emergency stop enabled, 2 = Emergency Overpressurizing enabled	If Emergency overpressurising is used Water radiator Freezing protection is disabled!
3.0->	4x5009	RW	CO2 automation	0	1		0 = Auto Home/Away/Boost control disabled, 1 = Auto Home/Away/Boost control enabled	Available only in units with CO2 sensor
4.0->	4x5116	RW	Boost mode Limit	0	2000	ppm	CO2 level when unit is working in boost speed.	
3.0->	4x5114	RW	Home mode Limit	0	2000	ppm	CO2 level when unit is working in home speed.	
3.0->	4x5115	RW	Away mode Limit	0	2000	ppm	CO2 level when unit is working in away speed.	
3.1->	4x5010	RW	RH automation	0	5		0 =Off, 1=Low, 2=Normal, 3=High, 4=Max, 5=Advanced	
4.0->	4x5010 - 1		- Low selection				Max boost level is 1/3 of Home-Boost level. Boost limit is 10% + RH average and full boost limit is 40% + RH average	
4.0->	4x5010 - 2		- Normal selection				Max boost level is 2/3 of Home-Boost level. Boost limit is 5% + RH average and full boost limit is 30% + RH average	
4.0->	4x5010 - 3		- High selection				Max boost level Boost level. Boost limit is 5% + RH average and full boost limit is 20% + RH average	
4.0->	4x5010 - 4		- Full selection				Max boost level Boost level. Boost limit is 5% and boosting is set immediately to max.	
4.0->	4x5117	RW	- Advanced selection Boost Limit	0	50	%	The ventilation is boosted steplessly when the humidity has risen from the average Boost limit defined amount.	
4.0->	4x5118	RW	- Advanced selection Max Boost Limit	0	50	%	The maximum ventilatin boost is reached when the humidity has risen the full boost limit defined amount from the average.	
4.0->	4x5178	RW	- Advanced selection Max allowed boost level	0	100	%	0% corresponds to the Home mode and 100% the Boost mode ventilation level	
3.1->	4x5119	RW	Boost delay	0	30	min	Boost start is delayed, so that ventilation is not disturbing during the shower	
3.1->	4x5120	RW	Boost during delay	0	25	%	Boost delay during the delay	
4.0->	4x5179	RW	Automation allowed in away mode	0	1		Allow function in away mode	
3.0	4x5011	RW	VOC automation	0	1		0 =Off, 1=Low, 2=Normal, 3=High, 4=Max, 5=Advanced	Available only in units with VOC sensor
4.0->	4x5011 - 1	RW	- Low selection				Max boost level is 1/3 of Home-Boost level. Boost limit is 1200ppm and full boost limit is 2000ppm	
4.0->	4x5011 - 2	RW	- Normal selection				Max boost level is 2/3 of Home-Boost level. Boost limit is 800ppm and full boost limit is 2000ppm	
4.0->	4x5011 - 3	RW	- High selection				Max boost level is Boost level. Boost limit is 700ppm and full boost limit is 1500ppm	
4.0->	4x5011 - 4	RW	- Full selection				Max boost level is Boost level. Boost limit is 500ppm and full boost limit is 1000ppm	
3.0->	4x5121	RW	- Advanced selection Boost limit	0	2000	ppm	The boost starts when the room temperature is over the set limit. Summer mode needs to be active and supply temperature cold enough.	
3.0->	4x5122	RW	- Advanced selection Full boost limit	0	2000	ppm	Temperature limit when boost is in max level	
4.0->	4x5180	RW	- Advanced selection Max allowed boost level	0	100	%	0% corresponds to the Home mode and 100% the Boost mode ventilation level	
4.0->	4x5181	RW	Automation allowed in away mode	0	1		Allow function in away mode	
4.0->	4x5169	RW	Summer mode boost	0	5		0 =Off, 1=Low, 2=Normal, 3=High, 4=Max, 5=Advanced	
4.0->	4x5169 - 1	RW	- Low selection				Max boost level is Home level. Boost gain: 6°C room temperature difference -> Max boost	
4.0->	4x5169 - 2	RW	- Normal selection				Max boost level is 1/2 of Home-Boost level. Boost gain: 4°C room temperature difference -> Max boost	
4.0->	4x5169 - 3	RW	- High selection				Max boost level is Boost level. Boost gain: 2°C room temperature difference -> Max boost	
4.0->	4x5169 - 4	RW	- Full selection				Max boost level is Boost level. Boost gain: 1°C room temperature difference -> Max boost	
3.0->	4x5170	RW	Advanced selection Boost limit (room temperature)	130	300	0.1°C	Ventilation is boosted when room temperature is higher the limit.	
3.1->	4x5125	RW	Advanced selection Full Boost limit (room temperature)	130	300	0.1°C	Ventilation is boosted to maximum when room temperature reach the limit.	
4.0->	4x5182	RW	Advanced selection Max allowed boost level	0	100	%	0% corresponds to the Home mode and 100% the Boost mode ventilation level	
4.0->	4x5183	RW	Automation allowed in away mode	0	1		Allow function in away mode	
3.0->	4x5005	RW	Cooking mode control	0	1		0 = Cooker hood damper is closed, 1 = Cooker hood damper is opened and cooking mode airflows are activated. 10h timer is activated.	Open cooker hood damper and activates cooking mode. Note that modbus control has 10 hour timer so function is active 10h or when controlled off or if unit is restarted.
3.0->	4x5020	RW	Cooker hood selection	0	4		0 = No Cooker hood, 1 = Cooker hood function with ventilation unit, 2 = Cooker hood with roof fan, 3 = Cooker hood with integrated fan, 4 = Recirculating cooker hood.	Cooker Hood function is activated when Casa cooker hood damper is opened
4.0->	4x5184	RW	Cooking mode Supply fan control	20	100	%	Measure building internal pressure and select supply fan control so that pressure is in balance.	
4.0->	4x5185	RW	Cooking mode Extract fan control	20	100	%	Measure building internal pressure and select extract fan control so that pressure is in balance.	
3.0->	4x5002	W	Fireplace function Activation	0	1		1 = Activate Fireplace function with timer, 0 = Stop Fireplace function	Firelace function activation
4.0->	4x5105	RW	Fireplace function level	0	2		0 = Low(1/3 of max), 1= Normal (2/3 of max), 2 = High (max)	Overpressure level
3.0->	4x5201	RW	Fireplace function visibility in User Panel	0	1		0 = Disabled, 1 = Enabled	User Panel visibility
4.0->			Central Vacuum Cleaner (CVC) function				Control only with CVC input	
3.0->	4x5113	RW	Central Vacuum Cleaner compensation	0	50	%	Fan speed compensation activated with IO input. Decrease Exhaust fan speed (Min speed Away) and increase supply fan speed if necessary.	

Heating / Cooling									
3.0->	4x5101	RW	Temperature setpoint	130	250	0.1°C	Supply temperature setpoint (Supply air control method = Supply air)		
4.0->	4x5168	RW	Temperature setpoint Summer	130	250	0.1°C	Supply temperature setpoint for summer period		
4.0->	4x5164	RW	Summer mode detection	0	2		0=OFF, 1=Auto, 2=ON		
4.0->	4x5166	RW	Summer mode detection outside limit	0	400	0.1°C	Summer mode is detected when outside temperature or outside average temperature is above limit		
4.0->	4x5167	RW	Summer mode Room temperature limit	100	400	0.1°C	Summer mode is detected when room temperature is above limit		Active if User control selected
4.0->	4x5186	RW	Winter mode limit	-100	300	0.1°C	Winter mode is activated when outside temperture is below the limit. Heat exchanger is controlled to maximum heating efficiency.		
4.0->	4x5107	RW	Winter mode Supply temperature setpoint for Away	130	250	0.1°C	Save energy on the heating period in away or travelling mode by selecting a lower supply air temperature setpoint		
4.0->	4x5171	RW	Winter mode Supply temperature setpoint for Travelling	130	250	0.1°C			
3.0->	4x5130	RW	Supply air control method	0	1		0 = Supply air, 1 = Room air		
4.0->	4x5187	RW	Room temperature setpoint	130	250	0.1°C	Supply/Room temperature controller setpoint		
4.0->	4x5188	RW	Winter mode Room temperature setpoint for Away	130	250	0.1°C	Save energy on the heating period in away or travelling mode by selecting a lower room air temperature setpoint		
4.0->	4x5189	RW	Winter mode Room temperature setpoint for Travelling	130	250	0.1°C			
3.0->	4x5133	RW	Room air control, Min Supply temperature setpoint	130	250	0.1°C	Room air control method controls the supply temperature setpoint between selected setpoint limits based on room temperature.		Available only if Room temperature control selected.
3.0->	4x5134	RW	Room air control, Max Supply temperature setpoint	130	250	0.1°C			
3.0->	4x5136	RW	Room air control (cooling), Min Supply temperature setpoint	10	50	0.1°C	If external cooling coil is installed, the room air control method controls the supply temperature setpoint between selected limits when cooling is active.		Available only if Room temperature control selected and with External Cooling device.
3.0->	4x5137	RW	Room air control (cooling), Max Supply temperature setpoint	10	50	0.1°C			
Duct coils									
4.0->			Internal Post heater				User outside temperature limit to disable internal postheater		Available only in units with internal postheater
3.0->	4x5129	RW	Heating Fresh air limit	-50	300	0.1°C	Heating is allowed when outside temperature is below the limit.		Available only in units with internal postheater
4.0->	4x5016	RW	External Post heater Liquid / Electrical	0	1		0 = Disabled, 1 = Water based post heater, 2= Electrical post heater		Available only in units with External Heating device
3.0->	4x5129	RW	Heating Fresh air limit	-50	50	°C	Heating is allowed when outside temperature is below the limit.		
3.0->	4x5153	RW	T7 External Supply Temperature Sensor	0	1		0=Swegon PTC, 1 = PT1000		Must be installed if external postheater is installed
3.0->	4x5156	RW	T6 Water Temperature Sensor Type	0	1		0=Swegon PTC, 1 = PT1000		Must be installed if water based postheater is installed
4.0->	4x5015	RW	External Post Cooling control / Ground liquid cooling	0	1		0 = Disabled, 1 = Liquid based post cooler, 2 = Water based post cooler		Available only in units with External Cooling device
3.0->	4x5135	RW	Cooling Fresh air limit	0	50	°C	Cooling is allowed when outside temperature is above the limit.		Available only in units with External Cooling device
4.0->	4x5153	RW	T7 External Supply Temperature Sensor	0	1		0=Swegon PTC, 1 = PT1000		Must be installed if external post cooler is installed
4.0->	4x5156	RW	T6 Water Temperature Sensor Type	0	1		0=Swegon PTC, 1 = PT1000		Must be installed if water based post cooler is installed
3.0->	4x5017	RW	External liquid coil (preheating / cooling)	0	1		0 = Disabled, 1 = Enabled, Note! define Relay output (DO) for Liquid preheater/precooler pump before function is enabled.		Function controls pump/valve relay based on outside temperature.
3.0->	4x5138	RW	External Pre heating Fresh air limit	-50	50	°C	Output for Preheating/cooling is activated when outside temperature is below the limit		Available only in units with External preheater/cooling device
3.0->	4x5139	RW	External Pre cooling Fresh air limit	-50	50	°C	Output for Preheating/cooling is activated when outside temperature is above the limit		Available only in units with External preheater/cooling device
4.0->	4x5154	RW	T8 External Outside Temperature Sensor	0	1		0=Swegon PTC, 1 = PT1000		External outside temperature measurement is used to for external preheater/cooler output control.
4.0->	4x5176	RW	External Preheater Liquid / Electrical	0	1		0 = Disabled, 1=Electrical preheater, 2 = Liquid based preheater		Available only in units with External preheater
External Connections									
3.0->	4x5157	RW	GIO 1 function	0	255		Disabled = 0 D1: 1=Emergency Stop, 2=Emergency Stop Resetted, 3= Stop, 4=Travelling, 5=Away, 6=Away/Home 7=Home, 8=Home+, 9=Boost, 10=Boost(pulse), 11=Fireplace (pulse), 12= Cooking mode, 13 = Central vacuum cleaner compensation, 14 = Fire alarm 15 = External device message, 16 = External device Alarm, 17= External device critical alarm, 18 = Modbus input, 19 = Output control, 20 = Max Cooling		
3.0->	4x5158	RW	GIO 2 function	0	255				
3.0->	4x5159	RW	GIO 3 function	0	255		Al:64 = Mode control, 65 = Stepless mode Control, 66 = Modbus measurement, 67 = Pa (supply) 68 = Pa(extract), 69 = Airflow(supply), 70 = Airflow(exhaust), 71 = RH, 72 = CO2, 73 = VOC, 74 = Temperature, 75 = Room pressure, 76=Outside humidity, 77= Supply air humidity		
3.0->	4x5160	RW	GIO 4 function	0	255		DO: 129 = Test/User panel controlled, 130 = Duct Damper, 131 = Alarm, 132 = Service, 133 = Critical Alarm, 134 = User stopped, 135 = Unit is running, 136 = Travelling, 137 = Away, 138 = Home, 139 = Home+, 140 = Boost , 141 = Fireplace, 142 = Humidity boost, 143 = Modbus output, 144 = Input controlled output, 145 = Heating active, 146 = Cooling active, 147 = Liquid Preheater/cooler active 148 = External Heating circuit, 149 = Internal Cooling		
3.0->	4x5161	RW	GIO 5 function	0	255				
3.0->	4x5162	RW	SET Relay 1 function	0	0		1 = Test/User panel controlled, 2 = Duct Damper, 3 = Alarm, 4 = Service, 5 = Critical Alarm, 6 = User stopped, 7 = Unit is running, 8 = Travelling, 9 = Away, 10 = Home, 11 = Home+, 12 = Boost , 13 = Fireplace, 14 = Humidity boost, 15 = Modbus output, 16 = Input controlled output, 17 = Heating active, 18 = Cooling active, 19, Preheater/cooler active 20 = External Heating circuit, 21 = Internal Cooling		
3.0->	4x5163	RW	SET Relay 2 function	0	0				
3.1->	4x5173	RW	GIO/SET DO POLARITY NO/NC	0	255	bit	BIT0 = GIO1, BIT1 = GIO2, BIT2 = GIO3, BIT3 = GIO4, BIT5 = GIO5 , BIT6 SET1DO, BIT7 =SET2 DO (0 = Normally open, 1=Normally closed)		
3.1->	4x5172	RW	AO4 Output type	0	4		0 = NA, 1 = Control, 2 = Stepless Control, 3 = Temp SP, 4 = Modbus		

GIO Modbus Control									
3.0->	4x5021	RW	GIO1 Relay output	0	1		0 = External Relay Open,1 = External Relay Closed		Select IO1 Type Relay Output and Function Modbus (4x5157 = 143)
3.0->	4x5022	RW	GIO2 Relay output	0	1		0 = External Relay Open,1 = External Relay Closed		Select IO2 Type Relay Output and Function Modbus (4x5158 = 143)
3.0->	4x5023	RW	GIO3 Relay output	0	1		0 = External Relay Open,1 = External Relay Closed		Select IO3 Type Relay Output and Function Modbus (4x5159 = 143)
3.0->	4x5024	RW	GIO4 Relay output	0	1		0 = External Relay Open,1 = External Relay Closed		Select IO4 Type Relay Output and Function Modbus (4x5160 = 143)
3.0->	4x5025	RW	GIO5 Relay output	0	1		0 = External Relay Open,1 = External Relay Closed		Select IO5 Type Relay Output and Function Modbus (4x5161 = 143)
3.0->	3x6349	R	GIO 1 DI status	0	1		0 = Open, 1 = Closed		Select IO1 to Modbus input (4x5157 = 18)
3.0->	3x6350	R	GIO 2 DI status	0	1		0 = Open, 1 = Closed		Select IO2 to Modbus input (4x5158 = 18)
3.0->	3x6351	R	GIO 3 DI status	0	1		0 = Open, 1 = Closed		Select IO3 to Modbus input (4x5159 = 18)
3.0->	3x6352	R	GIO 4 DI status	0	1		0 = Open, 1 = Closed		Select IO4 to Modbus input (4x5160 = 18)
3.0->	3x6353	R	GIO 5 DI status	0	1		0 = Open, 1 = Closed		Select IO5 to Modbus input (4x5161 = 18)
3.0->	3x6354	R	GIO 1 AI value	0	10000	mV	Analog input voltage		Select IO1 to Modbus meas. (4x5157 = 66)
3.0->	3x6355	R	GIO 2 AI value	0	10000	mV	Analog input voltage		Select IO2 to Modbus meas. (4x5158 = 66)
3.0->	3x6356	R	GIO 3 AI value	0	10000	mV	Analog input voltage		Select IO3 to Modbus meas. (4x5159 = 66)
3.0->	3x6357	R	GIO 4 AI value	0	10000	mV	Analog input voltage		Select IO4 to Modbus meas. (4x5160 = 66)
3.0->	3x6358	R	GIO 5 AI value	0	10000	mV	Analog input voltage		Select IO5 to Modbus meas. (4x5161 = 66)
3.0->	4x5026	RW	SET Relay 1 output	0	1		0 = External Relay Open,1 = External Relay Closed		Select SET Relay 1 to Modbus (4x5162 = 15)
3.0->	4x5027	RW	SET Relay 2 output	0	1		0 = External Relay Open,1 = External Relay Closed		Select SET Relay 2 to Modbus (4x5163 = 15)
3.0->	4x5028	RW	AO4 Output control	0	1000	0.01V	AO4 Voltage output control		Select AO4 Function to Modbus (4x5172 = 4)
Measurement inputs									
4.0->	4x5131	RW	Room Temperature sensor used for functions	0			0 = Internal Extract sensor temperature/ sensors package, 1 = T6, 2 = T7, 3 = T7, 4 = T9, 5 = GIO1, 6 = GIO2, 7 = GIO3, 8 = GIO4, 9 = GIO5, 10 = User Panel 1, 11 = UP2, 12 = UP3, 13 = UP4, 14 = UP5		Note when room temperature sensor is selected make sure that sensor measurement exists and is correct. Selected measurement is used i.e summer mode selection, summer night boost or room temperature control.
4.0->	4x5190	RW	T6 External Room Temperature Sensor type	0	1		0=Swegon PTC, 1* = PT1000 , Temperature can be read from 3x6278		SET Sensor inputs can be used as room temperature sensor if T6 is not reserved for water freeing protection sensor.
4.0->	4x5191	RW	T7 External Room Temperature Sensor type	0	1		0=Swegon PTC, 1* = PT1000, Temperature can be read from 3x6279		SET Sensor inputs can be used as room temperature sensor if T7 is not reserved for supply temperature sensor.
4.0->	4x5192	RW	T8 External Room Temperature Sensor type	0	1		0=Swegon PTC, 1* = PT1000, Temperature can be read from 3x6280		SET Sensor inputs can be used as room temperature sensor if T8 is not reserved for external outside temperature sensor.
4.0->	4x5193	RW	T9 External Room Temperature Sensor type	0	1		0=Swegon PTC, 1* = PT1000, Temperature can be read from 3x6281		SET Sensor inputs can be used as room temperature sensor if T9 is not reserved for external heating circuit sensor.
4.0->	4x5194	RW	GIO Temp measurement scale input low	0	10000	mV	AI (0-10V) measurement scaling values		
4.0->	4x5195	RW	GIO Temp measurement scale input high	0	10000	mV			
4.0->	4x5196	RW	GIO Temp measurement scale Temp output low	-500	500	0.1°C			
4.0->	4x5197	RW	GIO Temp measurement scale Temp output high	-500	500	0.1°C			
4.0->	4x5132	RW	Room Temperature Fine Tuning	-100	100	0.1°C	Room Temperature Fine tuning		
4.0->	4x5151	RW	T8 External Outside Temperature Sensor	0	2		0 = Internal fresh air sensor, 1 = T8 - External Swegon PTC, 2 = T8 - External PT1000		If accurate outside temperature measurement is requested external outside temperature sensor can be installed to T8 sensor input.
4.0->	4x5209	RW	RH measurement	0	5		0 = IO1, 1 = IO2, 2 = IO3, 3 = IO4, 4 = IO5, 5 = Internal sensor, 6 = Average, 7 = Highest, 8 = Lowest		
4.0->	4x5210	RW	GIO RH measurement scale input low	0	10000	mV	0-10V measurement scaling values		
4.0->	4x5211	RW	GIO RH measurement scale input high	0	10000	mV			
4.0->	4x5212	RW	GIO RH measurement scale rh output low	0	100	%			
4.0->	4x5213	RW	GIO RH measurement scale rh output high	0	100	%			
4.0->	4x5214	RW	CO2 measurement	0	5		0 = IO1, 1 = IO2, 2 = IO3, 3 = IO4, 4 = IO5, 5 = Internal sensor, 6 = Average, 7 = Highest, 8 = Lowest		
4.0->	4x5215	RW	GIO CO2 measurement scale input low	0	10000	mV	0-10V measurement scaling values		
4.0->	4x5216	RW	GIO CO2 measurement scale input high	0	10000	mV			
4.0->	4x5217	RW	GIO CO2 measurement scale CO2 output low	0	5000	ppm			
4.0->	4x5218	RW	GIO CO2 measurement scale CO2 output high	0	5000	ppm			
4.0->	4x5219	RW	VOC measurement	0	5		0 = IO1, 1 = IO2, 2 = IO3, 3 = IO4, 4 = IO5, 5 = Internal sensor, 6 = Average, 7 = Highest, 8 = Lowest		
4.0->	4x5220	RW	GIO VOC measurement scale input low	0	10000	mV	0-10V measurement scaling values		
4.0->	4x5221	RW	GIO VOC measurement scale input high	0	10000	mV			
4.0->	4x5222	RW	GIO VOC measurement scale VOC output low	0	5000	ppm			
4.0->	4x5223	RW	GIO VOC measurement scale VOC output high	0	5000	ppm			

Airflow adjustment							
3.0->	4x5029	RW	Commissioning Mode	0	9		0= Not in use,1=Away,2=Home,3=Boost, 4=Cooking mode, 5=End
3.0->	4x5302	RW	Away mode Supply fan speed	20	Home	%	fan speed
3.0->	4x5303	RW	Away mode Exhaust fan speed	20	Home	%	fan speed
3.0->	4x5304	RW	Home mode Supply fan speed	Away	Boost	%	fan speed
3.0->	4x5305	RW	Home mode Exhaust fan speed	Away	Boost	%	fan speed
3.0->	4x5306	RW	Boost mode Supply fan speed	Home	100	%	fan speed
3.0->	4x5307	RW	Boost mode Exhaust fan speed	Home	100	%	fan speed
4.0->	4x5020	RW	Cooker Hood mode	0	4		0=Not Selected, 1=Hood connected to ventilation unit, 2= Roof fan, 3=Integrated fan, 4=Recirculating cooker hood
4.0->	4x5184	RW	Cooking mode Supply fan speed	20	100	%	Cooking mode fan control
4.0->	4x5185	RW	Cooking mode Exhaust fan speed	20	100	%	Cooking mode fan control
3.0->	4x5318	RW	Ventilation control mode	0	5		0=Normal,1=PA Supply control, 2=PA Extract control, 3=PA control 4= l/s control
3.0->	4x5312	RW	Away mode Supply Pressure	0	255	PA	Ventilation Pressure
3.0->	4x5313	RW	Away mode Exhaust Pressure	0	255	PA	Ventilation Pressure
3.0->	4x5314	RW	Home mode Supply Pressure	0	255	PA	Ventilation Pressure
3.0->	4x5315	RW	Home mode Exhaust Pressure	0	255	PA	Ventilation Pressure
3.0->	4x5316	RW	Boost mode Supply Pressure	0	255	PA	Ventilation Pressure
3.0->	4x5317	RW	Boost mode Exhaust Pressure	0	255	PA	Ventilation Pressure

ALARMS									
3.0->	4x5141	RW	Service Reminder	0	1		0 = Disabled, 1 = Enabled	Service time can be resetted by writing 0 and 1 to this register	
3.0->	3x6343	R	Hours to next Service	0	10000	Hours		Available if Service Reminder enabled (see 4x5142 for Service Interval)	
3.0->	4x5142	RW	Service Reminder interval	0	12	months			
3.0->	3x6129	R	Service Info	0	1		0 = No Alarms, 1 = Unconfirmed Info Alarm	3x6136 Bit 9	
3.0->	4x5406	W	Reset All info alarms	0	1		1 Confirm Alarm, Register is cleared when command is processed.		
4.0->	3x6195	R	Critical Alarms (Ventilation stopped)	0	1		0 = No Alarms, 1 = Critical Alarm	Only in Genius control system	
3.0->	3x6132	R	Active Alarms	0	1		0 = No Alarms, 1 = Active Alarm		
3.0->	3x6133	R	Unconfirmed Info	0	1		0 = No Unconfirmed alarms, 1 =Unconfirmed alarms		
3.0->	3x6136	R	Active Alarms Bitwise - 1	0	16bit		See bitwise description in alarms notes. 0= No Alarm, 1= Active alarm.	See bit information below	
3.0->	3x6137	R	Resettable alarm bitwise - 1 (Past active alarm)	0	16bit		See bitwise description in alarms notes. 0= No past alarm, 1= Past active alarm	See bit information below	
3.0->	3x6117 / 3x6118	R	E011 Postheater failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 0 / 3x6137 Bit 0 (0000 0000 0000 0001)	
3.0->	3x6119 / 3x6120	R	E021 Preheater failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 1 / 3x6137 Bit1	
3.0->			Reserved					3x6136 Bit 2 / 3x6137 Bit2	
3.0->	3x6121 / 3x6122	R	E041 Freezing danger / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 3 / 3x6137 Bit 3	
3.0->	3x6125 / 3x6126	R	E051 Supply Fan Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 4 / 3x6137 Bit 4	
3.0->	3x6127 / 3x6128	R	E061 Exhaust Fan Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 5 / 3x6137 Bit 5	
3.0->	3x6101 / 3x6109	R	E151/E161 T1 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6102 / 3x6110	R	E152/E162 T2 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6103 / 3x6112	R	E153/E163 T3 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6104 / 3x6113	R	E154/E164 T4 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6105 / 3x6114	R	E155/E165 T5 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6106 / 3x6115	R	E156/E166 T6 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6107 / 3x6116	R	E157/E167 T7 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6108 / 3x6117	R	E158/E168 T8 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6134 / 3x6135	R	E159/E169 T9 Temperature Sensor Failure / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 6 / 3x6137 Bit 6	
3.0->	3x6131	R	E071 Emergency Stop	0	1		0 = No Alarms, 1 = Active Alarm	3x6136 Bit 7 /	
3.0->	3x6130	R	Reserved	0	1			/3x6317 Bit 8	
3.0->	3x6129	R	Service Info	0	1		0 = No Alarms, 1 = Service info	/ 3x6137 Bit 9	
3.0->	3x6123 / 3x6124	R	New Genius alarm / Genius unconfirmed alarm	0	1		0 = No Genius alarms, 1 = Active Genius alarm / Resettable alarm bitwise	3x6136 Bit 10 /3x6137 Bit 10 see Genius alarms	
3.0->	3x6143 / 3x6144	R	E111 Suppy temperature low alarm / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 11 / 3x6137 Bit 11	
3.0->	3x6145 / 3x6146	R	E121 Internal temperature high alarm / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 12 / 3x6137 Bit 12	
3.0->	3x6141 / 3x6142	R	Preheater temperature high alarm / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 13 / 3x6137 Bit 13	
3.1->	3x6147 / 3x6148	R	E131 Rotor RPM alarm / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 14 / 3x6137 Bit 14	
3.0->	3x6149 / 3x6150	R	Fan Control alarm / Resettable alarm bitwise	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6136 Bit 15 / 3x6137 Bit 15 (1000 0000 0000 0000)	
GENIUS CONTROL SYSTEM NEW ALARMS									
4.0->	3x6191	R	Active Alarms Bitwise - 2	0	16bit		See bitwise description in alarms notes. 0= No Alarm, 1= Active alarm	See bit information below	
4.0->	3x6192	R	Resettable Alarms Bitwise - 2 (Active alarm in the past)	0	16bit		See bitwise description in alarms notes. 0= No info, 1= Unconfirmed Info alarm	See bit information below	
4.0->	3x6151 / 3x6152	R	E171 Sensor package Failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 0 / 3x6192 Bit 0 (0000 0000 0000 0001)	
4.0->	3x6153 / 3x6154	R	E172 RH sensor Failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 1 / 3x6192 Bit 1	
4.0->	3x6155 / 3x6156	R	E173 CO2 sensor Failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 2 / 3x6192 Bit 2	
4.0->	3x6157 / 3x6158	R	E174 VOC sensor Failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 3 / 3x6192 Bit 3	
4.0->	3x6159 / 3x6160	R	E031 External Electrical Preheater Failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 4 / 3x6192 Bit 4	
4.0->	3x6161 / 3x6162	R	E181 External Electrical Postheater Failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 5 / 3x6192 Bit 5	
4.0->	3x6163 / 3x6164	R	E071 Internal PCB Temperature High / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 6 / 3x6192 Bit 6	
4.0->	3x6165 / 3x6166	R	Internal Parameter error / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 7 / 3x6192 Bit 7	
4.0->	3x6167 / 3x6168	R	E091 External Alarm / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 8 / 3x6192 Bit 8	
4.0->	3x6169 / 3x6170	R	E093 External device message / Resettable message	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 9 / 3x6192 Bit 9	
4.0->	3x6171 / 3x6172	R	E092 External critical alarm / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 10 / 3x6192 Bit 10	
4.0->	3x6173 / 3x6174	R	E101 External Fire detector alarm / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 11 / 3x6192 Bit 11	
4.0->	3x6175 / 3x6176	R	E141 Heat exchanger efficiency low / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 12 / 3x6192 Bit 12	
4.0->	3x6177 / 3x6178	R	Heat exchanger control failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6191 Bit 13 / 3x6192 Bit 13 (0010 0000 0000 0000)	
4.0->	3x6193	R	Active Alarms Bitwise - 3	0	16bit		See bitwise description in alarms notes. 0= No Alarm, 1= Active alarm	See bit information below	
4.0->	3x6194	R	Unconfirmed Alarms Bitwise - 3 (Active alarm in the past)	0	16bit		See bitwise description in alarms notes. 0= No info, 1= Unconfirmed Info alarm	See bit information below	
4.0->	3x6179 / 3x6180	R	E191 Cooling condenser temperature high / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 0 / 3x6194 Bit 0 (0000 0000 0000 0001)	
4.0->	3x6181 / 3x6182	R	E192 Cooling hotgas temperature high / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 1 / 3x6194 Bit 1	
4.0->	3x6183 / 3x6184	R	E193 Cooling pressure high / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 2 / 3x6194 Bit 2	
4.0->	3x6185 / 3x6186	R	E134 Rotor stall detection / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 3 / 3x6194 Bit 3	
4.0->	3x6187 / 3x6188	R	E133 Rotor driver overheat / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 4 / 3x6194 Bit 4	
4.0->	3x6189 / 3x6190	R	E132 Rotor connection failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 5 / 3x6194 Bit 5	
4.1->	3x6196 / 3x6197	R	E502 Indoor humidity / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 6 / 3x6194 Bit 6	
4.1->	3x6198 / 3x6199	R	E512 Cooling coil condense removal critical failure / Resettable alarm	0	1		0 = Not active alarm, 1 = Active / Resettable alarm	3x6193 Bit 7 / 3x6194 Bit 7	

DEVICE INFORMATION									
3.0->	3x6001	R	Device Firmware version major	0	99				
3.0->	3x6002	R	Device Firmware version minor	0	99				
3.0->	3x6003	R	Device Firmware build	0	999				
3.0->	3x6004	R	Parameter build	0	99				
3.0->	3x6005	R	Parameter minor build	0	99				
3.0->	3x6008	R	Model name[0:14]			ASCII	Model name ASCII code 3x16008 - 3x16024		
3.0->	3x6024	R	Unit Serial Number[0:23]			ASCII	Unit serial number ASCII code. 3x6024 - 3x6047		Direct Access to Service Portal
DIAGNOSTICS - MEASUREMENTS									
3.0->	3x6201	R	Fresh air temperature	-550	600	0.1°C	Ventilation unit internal outside air temperature (Filtered)		T1 sensor
3.0->	3x6202	R	Supply air before re-heater temperature	-550	600	0.1°C	Heat exchanger supply temperature		T2 or calculated from supply temperature T4 by scaling internal postheater effect.
3.0->	3x6203	R	Supply air temperature	-550	600	0.1°C	Effective supply air temperature. If external heater / cooling devices are installed external sensor is used.		T4 or T7 if external sensor is installed
3.0->	3x6204	R	Extract air temperature	-550	600	0.1°C	Extract air/Air from the room temperature		T3 or Sensor package
3.0->	3x6205	R	Exhaust air temperature	-550	600	0.1°C	Exhaust / Waste air temperature		T5 if sensor installed to unit
3.0->	3x6209	R	Water Radiator temperature	-550	600	0.1°C	Water battery freezing protection measurement		T6 if with water based radiator installed
3.0->	3x6211	R	External Outside air temperature	-550	600	0.1°C	External outside temperature		T8 if External PreHeater/Cooling control or if external outside sensor measurement is selected
3.0->	3x6206	R	Room air temperature	-550	600	0.1°C	Effective room air temperature, sensor defined with register		
4.0->	3x6278	R	T6 room temperature	-550	600	0.1°C	External room temperature sensor, type (PTC / PT1000) defined with register 4x1407		
4.0->	3x6279	R	T7 room temperature	-550	600	0.1°C	External room temperature sensor, type (PTC / PT1000) defined with register 4x1408		
4.0->	3x6280	R	T8 room temperature	-550	600	0.1°C	External room temperature sensor, type (PTC / PT1000) defined with register 4x1409		
4.0->	3x6281	R	T9 room temperature	-550	600	0.1°C	External room temperature sensor, type (PTC / PT1000) defined with register 4x1410		
4.0->	3x6282,3x6207	R	User Panel 1 temperature	-550	600	0.1°C	User panel internal temperature measurement		
4.0->	3x6283,3x6208	R	User Panel 2 temperature	-550	600	0.1°C	User panel internal temperature measurement		
4.0->	3x6284	R	User Panel 3 temperature	-550	600	0.1°C	User panel internal temperature measurement		
4.0->	3x6285	R	User Panel 4 temperature	-550	600	0.1°C	User panel internal temperature measurement		
4.0->	3x6286	R	User Panel 5 temperature	-550	600	0.1°C	User panel internal temperature measurement		
4.0->	3x6287	R	IO1 temperature	-550	600	0.1°C	0-10V temperature transmitter connected to IO1		
4.0->	3x6288	R	IO2 temperature	-550	600	0.1°C	0-10V temperature transmitter connected to IO2		
4.0->	3x6289	R	IO3 temperature	-550	600	0.1°C	0-10V temperature transmitter connected to IO3		
4.0->	3x6290	R	IO4 temperature	-550	600	0.1°C	0-10V temperature transmitter connected to IO4		
4.0->	3x6291	R	IO5 temperature	-550	600	0.1°C	0-10V temperature transmitter connected to IO5		
3.0->	3x6213	R	Room air CO2	450	2000	ppm	Effective CO2 measurement, define used sensor with register 4x5214		Filtered CO2 value
4.0->	3x6263	R	CO2 internal sensor	450	2000	ppm	Ventilation unit internal sensor		
4.0->	3x6258	R	CO2 IO1	0	5000	ppm	External CO2 sensor connected to IO1		
4.0->	3x6259	R	CO2 IO2	0	5000	ppm	External CO2 sensor connected to IO2		
4.0->	3x6260	R	CO2 IO3	0	5000	ppm	External CO2 sensor connected to IO3		
4.0->	3x6261	R	CO2 IO4	0	5000	ppm	External CO2 sensor connected to IO4		
4.0->	3x6262	R	CO2 IO5	0	5000	ppm	External CO2 sensor connected to IO5		
3.0->	3x6214	R	Room air RH (%)	0	100	%	Effective RH measurement, define used sensor with register 4x5209		
4.0->	3x6215	R	Room air AH (g/m3)	0	5000	0.01g/m3	Calculated absolute humidity, used in RH automation function		
4.0->	3x6216	R	Room air AH SetPoint (g/m3)	0	5000	0.01g/m3	Calculated absolute humidity boost limit, used in RH automation function		
4.0->	3x6269	R	RH internal sensor	450	2000	%	Ventilation unit internal sensor		
4.0->	3x6264	R	RH IO1	0	5000	%	External RH sensor connected to IO1		
4.0->	3x6265	R	RH IO2	0	5000	%	External RH sensor connected to IO2		
4.0->	3x6266	R	RH IO3	0	5000	%	External RH sensor connected to IO3		
4.0->	3x6267	R	RH IO4	0	5000	%	External RH sensor connected to IO4		
4.0->	3x6268	R	RH IO5	0	5000	%	External RH sensor connected to IO5		
3.0->	3x6217	R	Room air VOC	0	2000	ppm	Effective VOC measurement, define used sensor with register 4x5219		Available only in units with VOC sensor
4.0->	3x6275	R	VOC internal sensor	450	2000	ppm	Ventilation unit internal sensor		
4.0->	3x6270	R	VOC IO1	0	5000	ppm	External VOC sensor connected to IO1		
4.0->	3x6271	R	VOC IO2	0	5000	ppm	External VOC sensor connected to IO2		
4.0->	3x6272	R	VOC IO3	0	5000	ppm	External VOC sensor connected to IO3		
4.0->	3x6273	R	VOC IO4	0	5000	ppm	External VOC sensor connected to IO4		
4.0->	3x6274	R	VOC IO5	0	5000	ppm	External VOC sensor connected to IO5		
3.0->	3x6218	R	Supply Duct Pressure	0	500	Pa	External duct pressure sensor is needed		
3.0->	3x6219	R	Exhaust Duct Pressure	0	500	Pa	External duct pressure sensor is needed		
3.0->	3x6220	R	Supply Air Flow	0	500	l/s	External Air flow sensor is needed and K value needs to be adjusted		
3.0->	3x6221	R	Exhaust Air Flow	0	500	l/s	External Air flow sensor is needed and K value needs to be adjusted		
4.0->	3x6277	R	Room pressure	-500	500	0.1Pa	External measurement of building out/in pressure difference		

DIAGNOSTICS -UNIT STATUS									
3.0->	3x6301	R	Unit state	0	4			0 = Critical Stop, 1 = User Stopped, 2 = Starting, 3 = Normal, 4 = Commissioning	
3.0->	3x6308	R	Boost Time left	0	120	min		Timed Function remaining time	
3.0->	3x6309	R	Week Timer Active	0	10			0 = Weekly timer not Active, 1 = Stopped, 2 = Travelling, 3 = Away, 4 = Silent, 5 = Home, 6 = Home+, 7 = Boost, 8=NA, 9=NA, 10 = Weeklytimer interrupted	
3.0->	3x6307	R	Travelling mode Active	0	1			0 = Function Not Active, 1 = Travelling mode active	
4.0->	3x6325	R	Silent mode Active	0	1			0 = Function Not Active, 1 = Silent mode active, no boosting allowed	
3.0->	3x6335	R	Fireplace function active	0	1			0 = Function Not Active, 1 = Function Active	
3.0->	3x6336	R	Central Vacuum Cleaner function active	0	1			0 = Function Not Active, 1 = Function Active	
3.0->	3x6337	R	Cooking mode Active	0	1			0 = Function Not Active, 1 = Function Active	
3.0->	3x6302	R	Ventilation Speed state (compatibility to Smart)	0	4			0 = Stopped, 1= Away, 2 = Home, 3 = Boost	
4.0->	3x6434	R	Ventilation Speed state (Genius)	0	4			0 = Stopped, 1 = Travelling, 2 = Away, 3 = Home, 4 = Home+, 5 = Boost, 6 = Fireplace	
3.0->	3x6303	R	Supply Fan Control	0	100	%			
3.0->	3x6304	R	Exhaust Fan Control	0	100	%			
3.0->	3x6305	R	Supply Fan RPM	0	5000	1/min			Fan RPM measuremet is needed
3.0->	3x6306	R	Exhaust Fan RPM	0	5000	1/min			Fan RPM measuremet is needed
3.0->	3x6315	R	Automation control +/- of Home mode	-100	100	%		Ventilation is controlled steplessly from selected mode according this register	
3.0->	3x6310	R	CO2 Automation	-100	100	%		Fan control change based on CO2 automation	Available only in units with CO2 sensor
3.0->	3x6311	R	RH Automation	0	100	%		Fan control boost based on RH automation	Available only in units with RH sensor
3.0->	3x6312	R	VOC Automation	0	100	%		Fan control boost based on VOC automation	Available only in units with VOC sensor
3.0->	3x6313	R	Temperature boost	0	100	%		Fan control boost based on summer mode boost	
3.0->	3x6314	R	Fan Speed limit Control (Supply temperature low, ventilation reduction)	-100	0	%		Fan control change based on cold climate control. Note depending on unit model fan control change method may vary.	
4.0->	3x6382		Building pressure balance control	-50	50	%		Building pressure control, negative value decreases extract airflow and positive increases the airflow	External room pressure sensor is needed
4.0->	3x6370		Heating state					0 = Starting, 1 = Stopped, 2 = External Cooling, 3 = Internal Cooling, 4 = Internal Cooling limited, 5 = Summer mode control 6 = Heat exchanger control, 7 = Heating, 8 = Defrost 1, 9 = Defrost 2, 10 = Defrost 3	
4.0->	3x6320	R	Temperature Setpoint	13	25	°C		Effective supply temperature setpoint, controlled either user setpoint, summer mode, away or travelling mode or by room temperature controller	Available only in units with controlled re-heater
4.0->	3x6317	R	Combined Post heating external/internal control	0	100	%		Internal postheating 0 - 100% External Postheating 0 - 200%	
4.0->	3x6318	R	Internal post heating control	0	100	%		Internal electrical postheater control. Power (W) depend on post heater power	Available only in units with internal postheater
4.0->	3x6344	R	Internal Preheater control	0	100	%		Internal electrical preheater control. Power (W) depend on preheater power	Available only in units with Preheater
4.0->	3x6319	R	External post heating control water	0	100	%		External heating coil control (valve position). 100% equals 10V control signal	Available only in units with external postheater
4.0->	3x6322	R	External post heating control electrical	0	100	%		External heating coil control (power control). 100% equals 10V control signal	Available only in units with external postheater
4.0->	3x6321	R	External post cooling control	0	100	%		External cooling control (valve position). 100% equals 10V control signal	Available only in units with external post cooler
3.0->	3x6323	R	External post cooling active	0	1			External cooling control active	Available only in units with external post cooler
4.0->	3x6345	R	External Preheater control	0	100	%		External preheater control. Power (W) depend on preheater power	
4.0->	3x6331	R	External preheater/cooling output	0	1			0 = Not active, 1 = Active, 2= Idle for pump/valve anti jamming	
4.0->	3x6348	R	Heat exchanger bypass plate position	0	100	%		Bypass plate 100% full open 0% Closed	
4.0->	3x6332	R	Rotor control	0	1000	0.1%		% of max speed with 1 decimal accuracy	
4.0->	3x6234	R	Rotor rotating speed	0	2000	0.1/min		Rotation speed 0.1 rotations / minute	

ROOM CONTROLLERS						
4.1 >	4x1505	RW	Controller 1 ID	6	247	
4.1 >	4x1506	RW	Controller 2 ID	6	247	
4.1 >	4x1507	RW	Controller 3 ID	6	247	
4.1 >	4x1508	RW	Controller 4 ID	6	247	
4.1 >	4x1509	RW	Controller 5 ID	6	247	
4.1 >	4x1510	RW	Controller 6 ID	6	247	
4.1 >	4x1511	RW	Controller 7 ID	6	247	
4.1 >	4x1512	RW	Controller 1 Type	0	3	
4.1 >	4x1513	RW	Controller 2 Type	0	3	
4.1 >	4x1514	RW	Controller 3 Type	0	3	
4.1 >	4x1515	RW	Controller 4 Type	0	3	
4.1 >	4x1516	RW	Controller 5 Type	0	3	
4.1 >	4x1517	RW	Controller 6 Type	0	3	
4.1 >	4x1518	RW	Controller 7 Type	0	3	
4.1 >	4x1519	RW	Controller 1 Location	0	21	
4.1 >	4x1520	RW	Controller 2 Location	0	21	
4.1 >	4x1521	RW	Controller 3 Location	0	21	
4.1 >	4x1522	RW	Controller 4 Location	0	21	
4.1 >	4x1523	RW	Controller 5 Location	0	21	
4.1 >	4x1524	RW	Controller 6 Location	0	21	
4.1 >	4x1525	RW	Controller 7 Location	0	21	
4.1 >	4x1526	RW	Controller 1 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1527	RW	Controller 2 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1528	RW	Controller 3 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1529	RW	Controller 4 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1530	RW	Controller 5 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1531	RW	Controller 6 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1532	RW	Controller 7 Setpoint override (Only LUNA d MB controller)	0	1	
4.1 >	4x1542	RW	Controller 1 Setpoint	0	300	0,1°C
4.1 >	4x1543	RW	Controller 2 Setpoint	0	300	0,1°C
4.1 >	4x1544	RW	Controller 3 Setpoint	0	300	0,1°C
4.1 >	4x1545	RW	Controller 4 Setpoint	0	300	0,1°C
4.1 >	4x1546	RW	Controller 5 Setpoint	0	300	0,1°C
4.1 >	4x1547	RW	Controller 6 Setpoint	0	300	0,1°C
4.1 >	4x1548	RW	Controller 7 Setpoint	0	300	0,1°C
4.1 >	3x2253	R	Controller 1 Room temperature	0	300	0,1°C
4.1 >	3x2254	R	Controller 2 Room temperature	0	300	0,1°C
4.1 >	3x2255	R	Controller 3 Room temperature	0	300	0,1°C
4.1 >	3x2256	R	Controller 4 Room temperature	0	300	0,1°C
4.1 >	3x2257	R	Controller 5 Room temperature	0	300	0,1°C
4.1 >	3x2258	R	Controller 6 Room temperature	0	300	0,1°C
4.1 >	3x2259	R	Controller 7 Room temperature	0	300	0,1°C

Configure room controllers with individua ID's and define controller ID

0 = LUNA d MB, 1 = Proidual TRC-1A2T-MOD-24-W, 2 = Proidual CU-LH (1), 3= Proidual CU-LH (2)

0 = Controller disabled,
1 = Living room 1, 2 = Living room 2, 3 = Living room 3, 4 = Bedroom 1, 5 = Bedroom 2, 6 = Bedroom 3, 7 = Bedroom 4, 8 = Bedroom 5, 9 = Hallway, 10 = Kitchen, 11 = Dining room, 12 = Bathroom, 13 = Utility room, 14 = Walk-in closet, 15 = Storage room, 16 = Garage, 17 = Technical room, 18 = Zone 1, 19 = Zone 2, 20 = Zone 3, 21 = Zone 4

0 = Use controller knob setpoint,
1 = Override setpoint defined with register 4x1542...4x1548

Room temperature setpoint

Room temperature

Only LUNA d MB controller

LUNA d MB controller uses by default setpoint defined with the knob located on controller.