




VIEW A
(ALL ROUND DETAIL)

Note:
Dimension is flexible;
bear in mind building tie
wall pockets dimensions

**WALL POCKET
DETAIL**



VERTICAL BLADES
Damper can be installed
with the blades in the
vertical orientation with
the actuator mounted at
either the top or bottom.



NOTE:
**BUILDING TIE WALL POCKETS ON
THE SIDES AND BOTTOM**

actionair

by Swegon

© Swegon Air Management Limited
South Street, Whitstable, Kent CT5 3DU
Tel: +44 (0)1227 276100
Email: actionair@swegon.com
www.swegon.com/uk

Installation Detail

If your proposed installation details differ from that shown here, please discuss this with the authority having jurisdiction, referencing this documentation.

Deviation from this drawing requires approval of the relevant authority.

Connecting ductwork omitted for clarity. Ductwork must be independently supported. There must be an appropriate break-away joint between the damper and the connecting ductwork on both sides of the installation.

A minimum of 200mm between fire dampers installed in separate ducts and 75mm between fire damper and construction elements/edges needs to be observed unless otherwise specified in the drawing.



SCAN ME

Please refer to the DoP
for latest classifications
for CE/UKCA
compliance and the
Installation, Operation
and Maintenance Guide

G	ECN2227	MJB	29/04/22
F	ECN5134	MJB	05-02-21
E	EC1830	RTC	20/03/18
D	EC1770	MJB	20-02-18
Rev:	Comments:	By:	Date:
Drawn By:	swehrle	Date:	26/05/2011
Checked By:	Kimberley.M	Date:	29/04/2022
Approved By:	Gore.S	Date:	29/04/2022

Description:

VERTICAL APPLICATION
**SMOKE SHIELD &
INSTALLATION FRAME IN
MASONRY WALL**

Damper Size Range (mm)
200 x 200 to 1000 x 1000

Reference No:	Sheet	Rev
AAF10702	1 of 1	G

